

BESTIN AUTOMATION

An ISO 9001:2015 certified company


Proprietor: Amritpal Singh


Getting started with Tinkercad Circuits

Step 1: Go to: https://www.tinkercad.com/joinclass


Step 2: Enter the class code.

Step 3: Click on Join with Nickname and enter the nickname.





Step 4: Go to "Classes" section under your name.



Step 5: Enter your class.




DAV Public School


 $Amritpal_Singh$



Step 6:Select your activity.




Step 7: Select **Circuits**and then click on **Create new design**




Adding the components

Search and place these components one by one

- 1. Arduino
- 2. Breadboard
- 3. LED x 4
- 4. Resistor






Wiring


Common the cathode of all LED's to GND of Arduino.

Connect the anode of all LED's to the Arduino pins respectively.




Wiring

Change the resistor value to 330 ohms value by clicking on resistor.



Coding...

Select **Text** mode from top right corner and click **continue**.



Your main Code

```
void setup()
 pinMode(1, OUTPUT);
 pinMode(2, OUTPUT);
 pinMode(3, OUTPUT);
  pinMode(4, OUTPUT);
void loop()
  digitalWrite(1, HIGH);
  delay(1000); // Wait for 1000 millisecond(s)
  digitalWrite(1, LOW);
  delay(1000); // Wait for 1000 millisecond(s)
  digitalWrite(2, HIGH);
  delay(1000); // Wait for 1000 millisecond(s)
  digitalWrite(2, LOW);
  delay(1000); // Wait for 1000 millisecond(s)
  digitalWrite(3, HIGH);
  delay(1000); // Wait for 1000 millisecond(s)
  digitalWrite(3, LOW);
  delay(1000); // Wait for 1000 millisecond(s)
  digitalWrite(4, HIGH);
  delay(1000); // Wait for 1000 millisecond(s)
  digitalWrite(4, LOW);
  delay(1000); // Wait for 1000 millisecond(s)
```

Explanation of code

Set Pin number

Set pin ON/OFF
HIGH means ON
LOW means OFF

digitalWrite is a command
to turn ON or OFF a
particular pin
digitalWrite (1, HIGH);

delay(1000); // Wait for 1000 millisecond(s)
digitalWrite(1, LOW);
delay(1000); // Wait for 1000 millisecond(s)

Delay means wait time 1000ms = 1 seconds

Happy Coding

Journey begins from here.....

Thanks for your attention!

BESTIN AUTOMATION

An ISO 9001:2015 certified company